

Scale Master II Interface Kit - 6215

Interface Your Scale Master II with Your PC at the Push of a Button!



For Construction Estimators, Contractors or Anyone Who Works with Blueprints

The PC Interface Kit lets you transfer measured values directly from your Scale Master II into your PC spreadsheet (e.g., Excel, Lotus) or construction estimating programs. This saves you time and reduces costly keystroke errors! profits.

Packing Slip

- 3 m serial cable
- USB adaptor
- PC software (CD)
- Compatible with Windows 95, 98, 2000, ME, NT & XP
- Works with Excel, Lotus and most estimating programs
- User's Guide

Specifications

System Requirements:

PC Compatibility, Windows 95, Windows 98 or Windows 2000/NT; one serial or USB port

Memory Requirements:

Windows: 1.6 MB RAM for installation; 40K for operation of Connect Terminate & Stay Resident (TSR) program

Kit Includes:

3.0 m cable, one 3.5" disk for Windows and Installation/Operation Manual



BAMR (Pty) Ltd, PO Box 23973, Claremont, 7735, South Africa
Ph : 27 (0)21 683 2100, Fax : 27 (0)21 674 1485
Email : sales@bamr.co.za, Web : www.bamr.co.za